

34 Foot JPole Jr replacement element

34 Foot JPole Jr replacement element.

To install the element, place the longer element marked with red on the bolt marked with red, which is also a little shorter on the housing (AutoMatch), when you look at how far both bolts protrude out of the housing. Then the shorter element marked with black installs on the bolt marked with black that is extruding a little longer.

Never loosen the nut that is against the housing of the match. Instead, hold it still with one tool while loosening the nut that holds the ring connector in place.

NOTE - The longer element goes to the bolt marked with Red. If the Red mark has faded, then please note that the bolt that would be Red is three threads shorter than the other bolt.