34 Foot JPole Jr replacement element.

To install the element, place the longer element marked with red on the bolt marked with red, which is also a little shorter on the housing (AutoMatch), when you look at how far both bolts protrude out of the housing. Then the shorter element marked with black installs on the bolt marked with black that is extruding a little longer.

Never loosen the nut that is against the housing of the match. Instead, hold it still with one tool while loosening the nut that holds the ring connector in place.

NOTE – The longer element goes to the bolt marked with Red. If the Red mark has faded, then please note that the bolt that would be Red is three threads shorter than the other bolt.

Support Resources

- User Manuals: Alpha Antenna User Manuals hub.
- Videos: Related videos.
- Guidance / FAQs: Available HERE.
- Customer Reviews: Scroll to bottom of this page.

We Listen

We are dedicated to improving all of our systems. Specifications and descriptions are subject to change without notice.

5.0
★ ★ ★ ★ ★
★ ★ ★ ★ ★
Based on 3 reviews
5★
100
100%
4★
0%
3★

0%
2★
0%
1★
0%

Search
1-3 of 3 reviews
Most Recent

1. EM

   Protected_User_fccba5d2
   Verified owner
   July 19, 2026

   34 Foot JPole Jr replacement element

   Verified review - view original

2. KM

   Protected_User_dcd18945
   Verified owner
   November 30, 2025

   34 Foot JPole Jr replacement element

   Verified review - view original

3. P

Protected_User_0d3b2e36
Verified owner
October 7, 2023

★★★★★
★★★★★

34 Foot JPole Jr replacement element

Verified review - view original