

VHF, UHF, & 15-40 Meter EmComm Loop Mast + Inner/Outer Loop

This is the accessory to enable the EmComm tuning box to operate VHF, UHF, and 15 to 40 meters.